Fridge-Freezer / Réfrigérateur-Congélateur / Kühl-Gefrierkombination / Frigorifero-Congelatore / Koel-Vriescombinatie / Køle-Fryseskab / Frigorifico-Congélador

INSTRUCTION BOOK

GEBRAUCHSANWEISUNG

ISTRUZIONI D'USO

NOTICE D'UTILISATION

GEBRUIKSAANWIJZING

BRUGSANVISNING

INSTRUÇÕNES DE USO



ER8997B, ER8197B, ER8497BX

GB

FR

DE

IT

NL

DK

PO

818 16 24-00/1

Safety instructions GB

Your new fridge/freezer may have other functions compared to your previous one.
Carefully read these instructions to learn how the appliance works and how to care for it. Keep the instruction booklet. It will come in handy if you later sell the cabinet or give it to somebody else.
These warnings are provided in the interests of your safety. Ensure that you understand them all before installing or using the appliance. Your safety is of paramount importance. If you are insure about any of the meanings or warnings contact the Customer Care Department.

For the User

- The cabinet is intended for keeping foodstuff in a normal household as explained in this instruction booklet.
- Do not keep explosive gases or liquids in the refrigerator or freezer compartment. They may explode and cause injury and material damage.
- Do not let sharp objects come into contact with the refrigerating system on the back of and inside the cabinet. If the refrigerating system is punctured, the cabinet will be damaged and foodstuff inside may spoil.
- Do not keep carbonised drinks or bottles in the freezer compartment. The glass bottles may break.
- The cabinet is heavy. The edges and projecting parts of the cabinet may be sharp. Be careful when moving the cabinet and always use gloves.

Child Safety

- Pay attention so that small children do not gain access to the operating controls or the inside of the cabinet.

Scrapping old cabinets

When discarding the cabinet, hand it over to a recycling station. For more information, call your local city office or your dealer.

Contents GB

Safety instructions 2
Scrapping old cabinets 2

Contents 2

Description of the Appliance 3
Control Panel 4

Before use 5

Using fridge 5
To start the fridge and set the correct temperature 5
Temperature inside the fridge 6
Measuring the temperature 6
Switching off 6
Alarms and other features 6
Cabinet interior 7

Using the freezer 8
To start the freezer and set the correct temperature 8
Temperature inside the freezer 8
Switching off 8
Alarms and other features 8
Freezing 9
Suitable storage periods 10
Thawing 10
Cabinet interior 10

Hints and Tips 11
Saving energy 11
Food Storage 12
Protect the environment 12

Maintenance and Cleaning 12
Removing the ventilation grille 12
Cleaning 12
Defrosting the fridge 13
Defrosting the freezer 13
To Change the Light Bulb 13
When the appliance is not in use 14

Something Not Working 14
Guarantee Conditions 15
Customer Care Department 15
Service and Spare Parts 15

Technical specification 16

Installation 16
Unpacking 16
Remove the transport supports 16
Cleaning 17
Installing the cabinet 17
Electrical connection 18
Door Reversal 19

Description of the Appliance GB



Model ER8197B

1. Glass shelf
2. Bottle shelf
3. Vegetable drawer
4. Butter compartement
5. Door shelf
6. Egg holder
7. Bottle shelf
8. Freezing tray + accumulator
9. Freezer basket
10. Ventailation grille
11. Freezer calender



Model 8497BX

1. Glass shelf
2. Bottle shelf
3. Vegetable drawer
4. Butter compartment
5. Door shelf
6. Egg holder
7. Bottle shelf
8. Freezing tray + accumulator
9. Freezing basket
10. Ventilation grille
11. Freezer calender



Model ER8997B

1. glass shelf
2. cooling rack
3. vegetable drawer
4. diary compartment
5. door shelf
6. egg tray
7. bottle shelf
8. freezing tray + accumulator
9. freezer basket
10. ventilation grille
11. freezer calender
12. Removeable shelf

Control Panel



A. Refrigerator power switch
Switches the refrigerator on and off.

B. Temperature display
Shows the average temperature inside the refrigerator.

C. Temperature adjustment buttons/thermostat
Used to set the temperature in the refrigerator.

D. ACTION COOL button
Used to switch the Action Cool feature on and off.

E. Yellow indicator lamp
Lights when Action Cool is operating.

F. Freezer power switch
Switches the freezer on and off.

G. Temperature display
Shows the highest temperature inside the freezer.

H. Temperature adjustment buttons/thermostat
Used to set the temperature in the freezer.

I. FAST FREEZE button
Used to switch the fast Freeze feature on and off.

J. Yellow indicator lamp
Lights when fast Freeze is operating.

K. Alarm shut-off button
Used to turn the audible alarm off.

L. Red warning lamp
Flashes when one of the alarms in the cabinet has been triggered.

Before use

GB

Position and clean the cabinet as explained in the section ”Installation”.
Check that the drain hose at the rear of the cabinet discharges into the drip tray.



⚠ Before inserting the power plug into the outlet and switching on the cabinet for the first time, leave it standing upright for about 30 minutes, or for 4 hours if it was transported horizontally. Otherwise the compressor may sustain damage. This time will allow the oil sufficient time to return to the compressor.

Using fridge

GB

To start the fridge and set the correct temperature

Switching on:
Switch on the fridge by pressing the power switch.



Setting the temperature
Press the buttons until the desired temperature flashes in the temperature display (The temperature can be set between +1°C and +9°C.)
”+” raises the temperature.
”-” lowers the temperature.
A setting of 5°C is usually suitable for normal operation.



Once set, the temperature display shows ”-” until the temperature inside the fridge reaches +9°C or below.
Allow the cabinet to run for a period of 24 hours whenever the temperature setting is changed. This will allow the temperature to stabilise inside the cabinet.
It is not necessary to reset the temperature when the cabinet is switched on after it has been out of use. The thermostat recalls the previously set temperature.

Temperature inside the fridge

A suitable temperature inside the fridge is approx. +5°C. If the thermostat control is set to a too cold temperature, food with a high water content may start to freeze if it has been placed in the coldest places in the fridge. The picture shows the coldest and warmest places inside the fridge.
(+ warm, - cold)
Meat, fish and milk should be put in the coldest part of the cabinet.
The temperature will be affecteed by:

- How often the door is opened
- How much food is stored
- Position of the appliance (See chapter Installation)



Measuring the temperature

If the temperature is measured using a standard, single thermometer, this should be put in a glass of water centrally placed inside the cabinet. This will reflect the temperature inside the food products. Do not place the thermometer hanging or lying directly on the shelf.



Hints:

- Distribute foodstuffs to allow cold air to circulate freely between the products.
- Do not place food products directly against the cooling plate on the rear wall since they may freeze in this case.
- Also never put warm products into the cabinet. Wait until they have cooled down.
- Cover all foods properly to avoid odours and flavours from tainting other food.



Switching off

Switch off the cabinet by pressing the power switch. Keep the button pressed for approx. 1 second.

Power to the cabinet is completely interrupted only when the power plug is disconnected or the fuse is removed.



Alarms and other features

Door open alarm

If the fridgedoor remains open for more than 5 minutes, the red warning lamp starts flashing and an audible alarm sounds.
To switch off the alarm:
Press the ”alarm shut-off button”. The red warning lamp goes out when the door is closed.



Action cool

Use Action Cool to refrigerate a large quantity of products. When Action Cool is switched on, the temperature is automatically set to +2°C.
”A” is then displayed in the temperature display and the yellow indicator lamp lights. After about 6 hours, Action Cool is switched off and the temperature gradually returns to the previously set temperature. It is possible to switch off Action Cool manually by pressing the Action Cool button once more.



Cabinet interior

The shelves and door compartments are removable and can easily be re-arranged.
Certain shelves must be lifted up by the rear edge to enable them to be removed.
The lower door compartment and the glass shelf above the vegetable drawer must not be moved. They are required for proper air circulation inside the cabinet.
Shelves with a raised edge should be placed with the raised edge facing the rear wall of the cabinet, and thus prevent food products from touching the cooling plate.





The vegetable drawer has a removable plate to separate different vegetables.



Cooling Rack for Beverages (Model ER8997B)

To achieve maximum cooling in the cooling rack, heed the following:

- Place the rack immediately under the drip channel.
- Be sure the rack is cold before placing bottles and cans, that you want to cool, on it.
- Place large cans and bottles in the big recesses in the middle of the rack.
- Place small cans and bottles in the small recesses close to the cabinet wall.



Do not put the cooling rack in freezer to achieve quicker cooling.
Do not put loads heavier than 6.5kg onto the shelf.

Using the freezer

GB

To start the freezer and set the correct temperature



Switching on:
Switch on the freezer by pressing the power switch.
The alarm sounds if the temperature inside the freezer reaches room temperature. Turn off the alarm by pressing the switch-off button.

Setting the temperature
Press the buttons until the desired temperature blinks on the temperature display. (The temperature can be set between -15°C and -24°C.)
”+” increases the temperature.
”-” decreases the temperature.

Once set, the temperature display shows the current temperature inside the freezer.
Allow the cabinet to run for a period of 24 hours whenever the temperature setting is changed. This will allow the temperature to stabilise inside the cabinet.
It is not necessary to reset the temperature when the cabinet is switched on after it has been out of use. The thermostat recalls the previously set temperature.



Temperature inside the freezer

To ensure that foodstuff will keep for a long time, be sure that the temperature inside the freezer is -18°C or below. Please note, however, that the energy consumption increases as the temperature decreases.

Switching off

Switch off the cabinet by pressing the power switch. Keep the button pressed for approx. 1 second.

Power to the cabinet is completely interrupted only when the power plug is disconnected or the fuse is removed.

Alarms and other features

Door open alarm
If the door remains open for more than about 1 minute, the red indicator lamp starts flashing and an audible alarm sounds.
To switch off the alarm:
Press the alarm shut-off button. As long as the door remains open, the audible alarm will sound anew at 1-minute intervals. The red indicator lamp goes out when the door is closed.



Temperature alarm

If the temperature rises above -12°C, the red warning lamp flashes and an audible alarm sounds. The temperature display will then start to flash.

To switch off the alarm:

Press the alarm shut-off button to switch off the audible alarm. The temperature display will stop flashing.

The red warning lamp goes out when the temperature inside the freezer again falls below -11°C.

Find out what caused the alarm. See the chapter ”Something not working”.



Temperature memory

The temperature memory shows when an alarm has been triggered in the cabinet.

The temperature memory operates as follows:

When the temperature inside the freezer again falls below -11°C the audible alarm stops. The temperature display and the red warning lamp will flash to indicate than an alarm was triggered. When the alarm shut-off button is pressed, the display then displays the warmest temperature inside the cabinet during the alarm phase and the display stops flashing. By referring to the temperature display indication, it is possible to decide whether or not to discard the products inside the freezer.



<u>At about -12°C:</u>

Most food products can be immediately re-frozen. Ice cream is especially sensitive to temperature changes and should be consumed as soon as possible.

<u>At -9° – -2°C:</u>

Food products should be prepared (cooked) prior to eating or re-freezing them.

Freezing

You need not press the fast-freezing button when freezing smaller quantities of food during any 24-hour period.

In all other cases, press the fast-freezing button approx. 24 hours prior to placing the food in the freezer.

Fast-freezing is automatically switched of 48 hours after the button has been pressed.

Fast-freezing can be discontinued by pressing the fast-freezing button once again.

The yellow fast-freezing lamp remains lit as long as the fast-freezing button is engaged.



Practical advice on freezing

- When freezing products, use the top shelf, and if necessary the shelf beneth that.
- Place the foods directly on the freezer shelves.
- Spread out the products as much as possible to allow air to circulate between them.
- Do not place food products which are to be frozen directly against other frozen food. The heat from the unfrozen food may cause the frozen food to thaw on the surface.
- Once frozen, re-arrange the products and put them as close as possible to each other. The food will then stay cold longer in the event of a power failure.
- Do not freeze too much food at the same time. The freezing capacity of the unit is indicated in the specifications section.

A" (ACTION FREEZE) is displayed in the temperature display.



Check that the cabinet is operating and keeps the set temperature one day after switching it on for the first time. Only after then should the freezer be used to freeze fresh foodstuff.

Suitable storage periods

Food purchased in frozen condition: Follow the advice on the maximum storage period indicated on the packaging.
Food frozen at home:
Fatty and salty food should not be kept frozen for more than three months. Cooked food and low-fat food may be kept up to about six months. Lean food and berries can be kept for approximately one year.

Thawing

It is best to use the fridge to thaw food. Place the foodstuff on a plate with a raised edge to prevent liquids from running out. To quickly thaw food, put it in room temperature or in cold water. When using a microwave oven to thaw foodstuff, follow the manufacturer's instructions.

Cabinet interior

Freezer drawers

The freezer drawers make it easy to quickly and easily find the food package you want. To gain space, the drawers can be removed and the products can be put directly on the shelves. On all shelves, except the top shelf, it is possible to place products that protrude 20 mm from the front edge. This allows maximum use of the available space.
Do not remove the bottom drawer. It is required to assure proper air circulation.

Freezer tray
Use the freezer tray to freeze berries and vegetables. After about 4 hours the food will be thoroughly frozen and can then be packaged normally. Food that is frozen in this way will not stick together, enabling you to use only the amount required.



Cold accumulator
The cold accumulator will keep the food cold for longer after a power failure. The cold accumulator will be most effective when placed at the front of the fast-freezing tray.
When defrosting:
Place the cold accumulator on top of the frozen food to keep it cold.



Ice cubes
Fill the ice tray to max. 3/4 since water expands as it freezes. Release the ice cubes by twisting the ice tray.

If ice cubes are kept for a long time, they will dry out and the taste is affected. Thus, throw away old ice cubes and prepare new ones when needed.



Removeable shelf
(Model ER8997B): There is a middle shelf inside the freezer. Remove the shelf when large food products need to be frozen.



Hints and Tips

GB

Saving energy

- Pay careful attention to where the cabinet is placed. See the section ”Installation”. When installed correctly, the cabinet will consume less energy.
- Try to avoid keeping the door open for long periods, or opening the door to frequently as warm air will enter the cabinet, and cause the compressor to switch on unnecessarily often.
- Ensure there are no obstructions prevending the door from cloosing properly.
- Thaw frozen food in the fridge. This will ensure safer defrosting of foods and reduce the work of the refridgeration unit
- It is advisable to periodically clean the refrigeration systemat the back of the appliance with a duster or vacuum cleaner.
- Always leave warm food to cool down to room temperature before placing in the fridge.
- Food which is to be frozen (when cool) should be placed in the fridge before being transfered to the freezer.
- Avoid unnecessary frosting in the cabinet by packing all foodstuffs into airtight packages before placing them in the freezer.
- Carefully follow the advice on freezing products in the section ”Using the freezer”. This will prevent wasting energy.
- Do not set the temperature too low in the freezer. A suitable temperature is in the range of -18°C to -20°C .
- Defrost the freezer when the frost layer reaches a thickness of 3-5 mm.
- Make sure the door gasket is complete and always clean.

Food Storage

· To obtain the best results from your appliance, neither hot foods nor liquids which may evaporate, should be placed in the larder compartment.

· Avoid buying frozen food if you can not store it straight away. The use of an isulated container is advisable. When you arrive home place the frozen food in the freezer immediately.

· Ensure that food placed in the freezer is dated and labelled and used in date order to ensure that food is consumed at its best.

Remove suspect food from you refrigerator and clean, refer to cleaning and maintenance.

Protect the environment

· Hand over the cabinet packaging and discarded fridges and freezers to a recycling station. Contact your local city office or your closest dealer for more information.

· Keep foodstuff in re-usable containers. Cut down on disposable material as much as possible.

· When cleaning the cabinet, use a mild washing-up detergent.

· Follow the advice in the section ”Saving energy”

· The door gasket and coolant used in this cabinet will not harm the ozone layer.

· All parts in the packaging can be recycled.

· The cabinet has been designed for easy dismantling and subsequent recycling.

Maintenance and Cleaning GB

Removing the ventilation grille

The ventilation grille can be removed, e.g. to wash the grille.

Make sure the door is open when removing the ventilation grille. Unsnap the upper edge of the grille by pulling outward/downward. Then pull the grille straight out to completely remove it.





Cleaning

Clean the cabinet at regular intervals.

⚠ Do nt use detergents, abrasive powers, high perfumed cleaning products, wax polishes or cleaning products containing bleach or alcohol when cleaning the product.

Disconnect the appliance from electricity supply.

Internal Cleaning

Clean the inside and accossories with warm wather and bicarbonate of soda (5ml to 0,5 liter water) Rise and dry thoroughly.

Regularly check the door seals and wipe clean to ensur they are clean and free from debris.

Clean out the drip channel inside the fridge at regular intervals and ensure that the drip channel is clear att all times. If bocked carefully clear using a piece of flexible curtain wire inserted into the drain outlet to remove the blockage.





External Cleaning

Wash the outer cabinet with warm sopy water.

Remove the ventilation grille (see the section ”Removing the ventilation grille”) and vacuum-clean under the cabinet. Twice a year pull out the cabinet from the wall and vacuum-clean the backside of the cabinet, the refrigerating system and the compressor.

ⓘ When moving the cabinet, lift it by the front edge to avoid scratching the floor.

Defrosting the fridge

The fridge is defrosted automatically every time the compressor stops. Frost formation can be prevented by:

- not putting warm foodstuff inside the cabinet.
- avoiding frequently opening the door or keeping it open too long.
- do not place foodstuffs directly against the cold cooling plate.

Defrosting the freezer







A certain amount of frost will always form on the freezer shelves and around the top compartment. Defrost the freezer when the frost layer reaches a thickness of about 3-5 mm.

Remove the freezer drawers and place them on top of each other by turning every other drawer one half turn. Put insulating material around the drawers, e.g. blankets or newspapers.

The frozen products can also be packed closely together and be kept in a cold location, e.g. in the fridge.

Defrosting can be accelerated by placing bowls with hot water (not boiling) inside the freezer.

Take out the drain spout and place it in the bottom freezer drawer where water can collect.

Loosen the ventilation grille to enable the bowl to fit under the drain spout.

Carefully scrape off the ice when it starts to thaw. Use a wood or plastic scraper. Do not use sharp objects as these may damage the interior.

When all the ice has melted, clean and wipe the cabinet dry, then push the drain spout back in place. Switch on the cabinet and replace the frozen foodstuff.

⚠ Never use a hair drier or other heating appliances to speed up defrosting. Excessive heat may damage the plastic interior, and humidity could enter the electric appliance making it live.

To Change the Light Bulb



The light is switched on automatically when the door is opened. Before replacing the light bulb, disconnect the power plug from the outlet.

2. Cut the packaging around the bulb socket.

3. Keep the packaging on to hold the bulb when setting it into the socket. Do not touch the bulb with your bare fingers. Halogen light bulbs are sensitive to grease from the skin.

Use a clear, UV-blocked, low-pressure type halogen light bulb. Socket G4. Voltage 12 V. Power rating 20 W/bulb.

When the appliance is not in use

Disconnect the appliance from electricity supply.
Empty all foods and clean the appliance, leaving the doors ajar to prevent unpleasant smells.
If the cabinet will be kept on, ask somebody to check it once in a while to prevent the food inside from spoiling in case of a power failure.

Something Not Working GB

Before contacting your local Service Force Center check the following point:

Problem	Possible cause / Remedy
"□" is displayed in the temperature display. Or **The yellow Action Freeze and red warning lamp both flash.**	An error has occurred in measuring the temperature. Call your service representative. (The cooling system will continue to keep food products cold, but temperature adjustment will not be possible.)
Audible alarm + flashing red warning lamp. (It is too warm inside the freezer.)	Switch off the audible alarm by pressing the alarm shut-off button. The audible alarm could have been triggered by: The cabinet having been recently switched on and the temperature still being too high. See the chapter "Switching on and setting the temperature". The door may have been open for so long that the 'door open' alarm was triggered.
It is too warm inside the refrigerator.	Set a lower temperature. Put food products in the right place inside the refrigerator. See the chapter "Temperature inside the refrigerator". Distribute the food products to allow cold air to circulate around them. Make sure that the door is completely closed and that the insulating strip is complete and clean.
It is too cold inside the refrigerator.	Set a higher temperature. Vegetables and other products that are easily frozen have been placed on a "too cold" shelf. See the chapter "Temperature inside the refrigerator".
There is water on the cooling plate inside the refrigerator.	This is normal. During automatic defrosting, frost thaws on the cooling plate.
Water is running inside the refrigerator.	Clean the water drain and drain hole inside the refrigerator using e.g. cotton swabs or a bottle cleaner brush. Some food products could have been placed causing the water from running into the drain.
Water comes out on the floor.	Place the drain hose at the back of the cabinet above the drain bowl. See the chapter "Before using the cabinet the first time".
It is too warm inside the freezer.	Set a lower temperature. Make sure that the door is completely closed and that the insulating strip is complete and clean. If warm food products have been put inside the freezer, wait for a couple of hours and then check the temperature again. Distribute the food products to allow cold air to circulate around them.
It is too cold inside the freezer.	Set a higher temperature. Action Freeze could have been switched on.

Too much frost and ice are produced.	Make sure that the door is completely closed and that the insulating strip is complete and clean. Set a higher temperature.
The compressor operates continuously.	Set a higher temperature. Make sure that the door is completely closed and that the insulating strip is complete and clean.
The cabinet does not operate at all. Cooling or interior light does not operate. No indicator lamps light.	The power plug is not properly connected. The fuse has blown. The cabinet is not switched on. Power does not reach the cabinet. (Try connecting another electrical device to the power outlet.)
Sound level in cabinet is too high.	The refrigerating system will always produce some sounds. A pulsing sound is heard when coolant is pumped inside the cooling pipes. A ticking sound from the thermostat can be heard when the compressor switches on and off. The sound level varies depending on the operation of the cabinet. If you feel the sound level is incorrect: Make sure the pipes at the back of the cabinet not touch each other. Carefully bend them if they do. If the cushion spacers (between the cabinet wall and pipes) come loose, put them back in place again. Carefully follow the instructions in the chapter ”Installing the cabinet”.
Power failure	Do not unnecessarily open the cabinet, except when the power outage seems to be long, in which case the food products should be moved to another cabinet that works. In case the frozen products are still hard following the power outage, they may be immediately refrozen. If the food products have thawed but still are fresh and smells alright, they may be used, however they should be prepared before re-freezing or eating them.

Guarantee Conditions

See Guarantee Conditions on the Registration Card.

Customer Care Department

Fore general enquiries concerning your Electrolux appliance or futher information on Electrolux products, you areinvited to contact our Costumer Care Department by letter or phone as follows:

Customer Care Department
Electrolux
Electrolux House
Hambridge Road
Newbury
Berkshire
RG14 5EP

Phone: 01635 521313

Service and Spare Parts

In the event of your appliance requiring service, or if oyu wish to purchase spare parts please contact your local Electrolux Service Force Centre by telephoning:
XXXXXXXXXXX
Your call be routed the Service Force Centre covering your post code area. The address of your local Service Force Center ids detailed in the accompanying Customer Care Book.
Before calling out an engineer, please ensure you have read the details under the heading ”Something Not Working”
When you contact the Service Center you will need to give the following details.They will be found inside your appliance.

MOD (modell):.....

PROD.NO (model number):.....

SER:NO (serial number):.....

Purchase date.....

Technical specification

GB

Model	ER8197B	ER8497BX	ER8997B
Volume fridge Volume freezer	193 l 97 l	240 l 85 l	240 l 127 l
Width	595 mm	595 mm	595 mm
Height	2000 mm	1800 mm	2000 mm
Dybde	600 mm	600 mm	600 mm
Energy consumption	336 kWh/year	460 kWh/year	511 kWh/year
Energiklasse	A	B	B
Rated power	160W	160W	160W
Weight	89 kg	87 kg	94 kg
Freezing capacity	12 kg/24 hours	12 kg/24 hours	12 kg/24 hours
Number of compressors	2	2	2

Installation

GB

Unpacking

Unpack the cabinet and check that it is in good condition and free of any transport damage. Notify the dealer immediately of any damage. Hand the packaging over for recycling. For more information, contact your local city office or the dealer.

⚠ Do not allow children to play with the packaging. The plastic film can cause suffocation.

Remove the transport supports

Remove the tape and the transport supports from

- the door sides
- inside the door hinges
- the shelves

Remove the transport support on the glass shelf by pushing the support forward along the edge of the shelf until it stops at the protuberance of the shelf. Take hold of the rear edge of the glass shelf and pull the shelf and transport support forward until the shelf tilts and the transport support can be removed. Some models are fitted with a silencing pad under the cabinet. Do not remove this pad.



Cleaning

Wash the inside of the cabinet using lukewarm water, a mild washing-up detergent and a soft cloth.

Installing the cabinet

To otain the best performance from the cabinet, ensure :

- the cabinet is placed in a dry, cool place and is not exposed to direct sunlight.
- the cabinet is not placed close to a source of heat, e.g. a cooker or dishwasher.
- the room in which the cabinet is placed has a temperature of +16°C to +32°C.
- the cabinet is level.The cabinet should not lean against any wall. If necessary adjust the feet using the supplied adjustment spanner.
- there is good air circulation around the cabinet and that the air channels below and behind the cabinet are not blocked. The ventilation space above the cabinet and any grocery/top cabinet must be at least 200 cm^2. The ventilation space can either be

a) directly above the cabinet, or
b) behind and above the top cabinet. In this case, the space behind the cabinet must be at least 50 mm deep.

Check that the drain hose at the rear of the cabinet discharges into the drip tray.

If the cabinet is placed in a corner and the side with the hinges faces the wall, the distance between the wall and the cabinet must be at least 10 mm to allow the door to open enough so that the shelves can be removed.





Electrical connection

⚠ This appliance must be earthed.

If the plug that is fitted to your appliance is not suitable for your socket outlett, it must be cut of and the appropriate plug fitted.
Remove the fuse from the cut off plug.The cut off plug should then be disposed of to prevent the hazard of socket inanother part of your home.
The wires in the mains lead are coloured in accordance with the following code:

Green and yellow -Earth
Blue -Neutral
Brown -Live

If you fit your own plug, the colours of the Wires in the mains lead of your appliance may not correspond with the markings identifying the terminals in your plug, proceed as follows:

Connect the Green and Yellow (earth) wire to the terminal in the plug which is marked with the letter ”E” or the earth symbol ⏚ or coloured greeen and yellow.

Connnect the blue (neutral) wire to the terminal in the plug which is marked with the letter ”N” or coloured black

Connect the brown (live) wire to the terminal in the plug which is marked with the letter ”L” or coloured red.

The plug moulded onto the lead incorporates a fuse. For replacement, use a 13amp BSI362 fuse. Onely ASTAor BSI approved fuses should be used.
The plug must not be used if the fuse cover/carrier is lost. The cover/carrier is indicated by the coloured insert at the base of the plug.
A replacement cover/carrier must be obtained from your local Service Force Centre.

Door Reversal

1. Close the cabinet and pull out the plug from the electrical outlet.

2. Remove the ventilation grille. There is a part on the grille that can be removed. Remove it and put it on the other side.

3. Put the cabinet on a wooden board when it is laid down. Later, when raising the cabinet, it will be easier to grip under the cabinet thanks to the board.



4. Unscrew the lower hinge and remove the lower door. Unscrew the upper hinge pin and remove the upper door.

On the centre beam:

5. Remove the plastic plugs by driving a drift into them and rocking them loose.

Move the centre hinge unit to the other side. Flatten the threads in the holes remaining from the hinges and insert new plastic plugs.

6. On the doors: Change the positions of the door fittings. Put a new plug in the hole on the lower door.

Replace the upper door and secure the upper hinge pin.

7. Replace the lower door. Change the position of the hinge pin of the lower hinge. Then secure the hinge.

Remove any play in the door by adjusting the height of the lower hinge with the supplied spanner. Secure with the lock-nut.

Raise the cabinet and replace the ventilation grille.

8. Unscrew the handle. Carefully press in the plastic plugs on the opposite side using a drift. Secure the handle in the plug holes. Then press the supplied plastic plugs into the holes to which the handle was previously fitted.

Model ER8497BX:
9. To transfer the handle.
Unscrew the screws. Fit the handle onto the opposite side by turning it one half circle.

10. Put the cabinet in position. Check that it stands straight. See the section ”Positioning the cabinet”.









Model ER8497BX:



CE